







PREPARE THE GROUND, UNWRAP THE PACKAGE,
LAY OUT THE COMPONENTS, FIND THE TOOLS.

Dillon /DIANA 40



4x40 × 130

4x50 × 900




5x70 × 10

6x140 × 60

M8x70 × 12

1,4x40 × 45

LAY OUT THE FOUNDATION BEAMS AND SQUARE IT BY MEASURING FROM CORNER TO CORNER.




MAKE SURE THAT THE FOUNDATION IS INSTALLED ON A LEVEL SURFACE. CHECKING ALL DIRECTIONS, INCLUDING CORNER TO CORNER. 2%





ATTACH FOUNDATION BEAMS
WITH SCREWS.


Dillon /DIANA 40

6x140 × 16
Ø 5 mm




LAY OUT THE **BOTTOM** LOGS,
ATTACH TO THE FOUNDATION.

5×70  $\times 4$ 6×140  $\times 14$
 $\varnothing 4 \text{ mm}$  $\varnothing 5 \text{ mm}$ 




Dillon /DIANA 40





THE WALL **LOGS** WILL HANG OVER
THE FOUNDATION **BEAMS** BY
APPROXIMATELY 5MM. THIS OVERHANG
IS DESIGNED AS A RAIN DRIP. **4%**

ATTACH THE FIRST ROW OF
WALL LOGS INTO THE BOTTOM
LOGS WITH **SCREWS**.




Dillon /DIANA 40





AFTER PLACING 3-4 ROWS OF WALL LOGS, TAP EACH WALL LOG IN PLACE USING A HAMMER AND THE HITBLOCK PROVIDED, TO TIGHTEN THE LOGS.

Dillon /DIANA 40




SLIDE THE DOOR AND WINDOW IN,
ATTACH THE HANDLES.

Dillon /DIANA 40




DON`T FORGET TO
TIGHTEN THE LOGS AFTER
EVERY 3-4 ROWS.

Dillon /DIANA 40





SLIDE THE **WINDOWS** IN,
ATTACH THE **HANDLES**.

Dillon /DIANA 40




INSTALL THE DOOR, INSERT CM1 BETWEEN THE WINDOWS AND THE DOOR, ATTACH THEM TO CM1 WITH SCREWS.

4x40
× 16




ATTACH LATHS (LTH1) INTO
WINDOWS AND INTO CM1
WITH SCREWS.

4x40
× 18






Dillon /DIANA 40



INSTALL THE GABLES WITH LONG SCREWS TO THE WALL LOGS ON THE FRONT AND REAR WALLS.

6x140 × 4



Ø 5 mm



INSTALL THE ROOF PURLINS AND ATTACH THEM WITH SCREWS.

Dillon /DIANA 40


6x140 × 10
Ø 5 mm



PLACE THE FIRST **ROOFBOARD** FLUSH WITH THE **END** OF THE PURLINS AND ATTACH WITH 8 SCREWS, 4 **INTO** EACH NEXT. SAW THE LAST **BOARD** TO MAKE IT FIT.

4x50  × 448



Dillon /DIANA 40



FOR THE FASCIA TRIMS
INSERT **SCREWS** AFTER EVERY
0,5 METERS.

4x40
× 52




Dillon /DIANA 40



EAVES EDGES GO ON TOP
OF THE ROOFING*.
*(NOT INCLUDED)

4x40 × 20

Ø 3 mm



Dillon /DIANA 40



ATTACH ROMBS WITH SCREWS.

Dillon /DIANA 40

4x40 × 4




Ø 3 mm

ROMB



16 SCREWS INTO THE FIRST FLOORBOARD,
8 INTO EACH NEXT, SAW THE
LAST BOARD TO MAKE IT FIT.



4x50
× 416



SAW THE **BASEBOARDS**
AND ATTACH WITH NAILS
AT **EVERY 0,5** METERS.

1,4×40
× 45



Dillon /DIANA 40




DRILL THROUGH THE WALL, HOLE MUST BE AT THE BOTTOM OF THE OVAL, ATTACH WITH BOLT.

M8x70 × 12

Ø 8 mm





WINDBOARD




IF DOOR IS TILTED,
PUSH THE DOOR FRAME SO
THAT ALL CORNERS ARE 90°.

Dillon /DIANA 40



IF **DOORS** ARE IN DIFFERENT HEIGHTS
OR THERE IS A GAP **BETWEEN** THEM,
ADJUST 3 SCREWS ON DOOR HINGES.

Dillon /DIANA 40



WHEN THE **HOUSE** IS ASSEMBLED, YOU SHOULD **COVER** THE TIMBER WITH **WOOD** PROTECTIVE SEAL, PAINT OR **STAIN** AS SOON AS POSSIBLE TO AVOID DETERIORATION TO THE **WOOD**.

Dillon /DIANA 40

